



Easy steps on how to light the

wood burning stove



Step 1 Riddle the ash down through the grate and empty the pan beneath if necessary. Place 6-8 sticks of kindling, just like a Jenga, and place a <u>single</u> Flamers firelighter into the middle.



Step 3 Light the Flamers firelighter and close the door, but leaving slightly ajar for max airflow. Allow the fire to burn for about 10 minutes. Close door after a few minutes. Tip: Don't be tempted to move any logs, just leave it to burn





Step 2 Take about 3-4 smaller kiln dried logs and place over the kindling so that it looks a bit like a Tipi. Open stove vents as per operator's manual.



Step 4 Add more logs as required to build a really good base to the fire, then reduce air flow via controls, to suit requirements.

Tip: Always add more logs at a vertical angle making sure there are plenty of air gaps between them.

Don't reduce air flow too much to stop flames

- ONLY use kiln dried logs for maximum heat output and remember it means you will need far less wood and ensures the stove glass and flue are kept clean.
- DO NOT forage wood from the forest, and never damage hedgerows or trees by removing wood.

If you enjoy any of the Certainly Wood products – kiln dried logs, kindling or Flamers natural firelighters, please visit their website for more details www.certainlywood.co.uk. They are a company sourcing all their wood from local sustainable woodland and drying the wood in wood fired

kilns! If you have a wood burner at home, they can provide you with bulk deliveries delivered direct to your home Certwood/POS/How to light your fire – Generic stove